#### STEP 1:

Mount junction box with suitable fasteners.

(NOT PROVIDED)

#### STEP 2:

Run supply wires (ground, line and neutral) to box through conduit. Connect ground wire to ground boss and green screw.

#### STEP 3:

Silicone seal conduit openings around wires, gaskets, and hole plugs.

NOTE: Failure to properly seal wire ways / conduit opening will allow mointure inside the fixture and void the warranty.

#### STEP 4:

Stack the lens, lens gasket, LED module

Do not touch LEDs with fingers - static shock can hurt LED

and housing gasket.

Pass the screws (2x) through stacked assembly.

STEP 5:

Assemble stacked assembly to junction box.

# SPECIFICATION:

WATT: 11 W

FREQUENCY: 60 Hz POWER FACTOR: > .9

**ENVIRONMENT: WET LOCATION** 

INPUT VOLTS: 120 VAC, 0.09 A

-40° F [-40° C] to 122° F [50° C]

## ATTENTION:

Fill conduit around wires & plugs with sealant.



BEFORE AFTER

### **WARNINGS AND CAUTIONS:**

A. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRIC CODES.

The manufacturer assumes no responsibility for improper installation, or application of this lighting fixture.

- B. USE MIN 90° C SUPPLY CONDUCTORS.
- C. Turn off all electricity before installation or servicing.
- D. This "FIXTURE MUST BE GROUNDED".
- E. NO SERVICEABLE PARTS.
- F. Sealing of wire opening is necessary to prevent condensation from forming and water collection inside the fixture. Failure to properly seal fixture will VOID warranty.





